# **Review and Background**

#### <u>Amdahl's Law</u>

<u>Speedup</u> = time<sub>without enhancement</sub> / time<sub>with enhancement</sub>

An enhancement speeds up fraction f of a task by factor S time<sub>new</sub> = time<sub>orig</sub>·( (1-f) + f/S )  $S_{overall} = 1 / ( (1-f) + f/S )$ 



#### The Iron Law of Processor Performance



We will concentrate on CPI, others are important too!

# Performance

- *Latency* (execution time): time to finish one task
- *Throughput* (bandwidth): number of tasks/unit time
  - Throughput can exploit parallelism, latency can't
  - Sometimes complimentary, often contradictory
- Example: move people from A to B, 10 miles
  - Car: capacity = 5, speed = 60 miles/hour
  - Bus: capacity = 60, speed = 20 miles/hour
  - Latency: car = 10 min, bus = 30 min
  - Throughput: car = 15 PPH (count return trip), bus = 60 PPH

#### No right answer: pick metric for your goals

### Performance Improvement

- Processor A is X times faster than processor B if
  - Latency(P,A) = Latency(P,B) / X
  - Throughput(P,A) = Throughput(P,B) \* X
- Processor A is X% faster than processor B if
  - Latency(P,A) = Latency(P,B) / (1+X/100)
  - Throughput(P,A) = Throughput(P,B) \* (1+X/100)
- Car/bus example
  - Latency? Car is 3 times (200%) faster than bus
  - Throughput? Bus is 4 times (300%) faster than car

### Partial Performance Metrics Pitfalls

- Which processor would you buy?
  - Processor A: CPI = 2, clock = 2.8 GHz
  - Processor B: CPI = 1, clock = 1.8 GHz
  - Probably A, but B is faster (assuming same ISA/compiler)
- Classic example
  - 800 MHz Pentium III faster than 1 GHz Pentium 4
  - Same ISA and compiler

# Averaging Performance Numbers (1/2)

- Latency is additive, throughput is not Latency(P1+P2,A) = Latency(P1,A) + Latency(P2,A) Throughput(P1+P2,A) != Throughput(P1,A)+Throughput(P2,A)
- Example:
  - 180 miles @ 30 miles/hour + 180 miles @ 90 miles/hour
  - 6 hours at 30 miles/hour + 2 hours at 90 miles/hour
    - Total latency is 6 + 2 = 8 hours
    - Total throughput is *not 60* miles/hour
      - Total throughput is **only 45** miles/hour! (360 miles / (6 + 2 hours))

#### Arithmetic mean is *not* always the answer!

# Averaging Performance Numbers (2/2)

- <u>Arithmetic</u>: times
  - proportional to time
  - e.g., latency
- *Harmonic*: rates
  - inversely proportional to time
  - e.g., throughput
- *Geometric*: ratios
  - unit-less quantities
  - e.g., speedups

 $\frac{1}{n}\sum_{i=1}^{n}Time_{i}$ 





#### Memorize these to avoid looking them up later

### Parallelism: Work and Critical Path

- *Parallelism*: number of independent tasks available
- Work (T1): time on sequential system
- <u>Critical Path</u> (T $\infty$ ): time on infinitely-parallel system
- <u>Average Parallelism</u>:  $P_{avg} = T1 / T\infty$
- For a *p*-wide system:  $T_p \ge max\{T1/p, T\infty\}$  $P_{avg} >> p \implies T_p \approx T1/p$



#### Locality Principle

• Recent past is a good indication of near future

<u>Temporal Locality</u>: If you looked something up, it is very likely that you will look it up again soon

<u>Spatial Locality</u>: If you looked something up, it is very likely you will look up something nearby soon

# Power vs. Energy (1/2)

- *Power*: instantaneous rate of energy transfer
  - Expressed in Watts
  - In Architecture, implies conversion of electricity to heat
  - Power(Comp1+Comp2)=Power(Comp1)+Power(Comp2)
- *Energy*: measure of using power for some time
  - Expressed in Joules
  - power \* time (joules = watts \* seconds)
  - Energy(OP1+OP2)=Energy(OP1)+Energy(OP2)

# Power vs. Energy (2/2)



# Why is energy important?

- Because electricity consumption has costs
  - Impacts battery life for mobile
  - Impacts electricity costs for tethered
    - Delivering power for buildings, countries
    - Gets worse with larger data centers (\$7M for 1000 racks)



# Why is power important?

- Because power has a peak
- All power "spent" is converted to heat
  - Must dissipate the heat
  - Need heat sinks and fans
- What if fans not fast enough?
  - Chip powers off (if it's smart enough)
  - Melts otherwise
- Thermal failures even when fans OK
  - 50% server reliability degradation for +10oC
  - 50% decrease in hard disk lifetime for +15oC



#### Power

- Dynamic power vs. Static power
  - Static: "leakage" power
  - Dynamic: "switching" power
- Static power: steady, constant energy cost
- Dynamic power: transitions from  $0 \rightarrow 1$  and  $1 \rightarrow 0$

# Power: The Basics (1/2)

- Dynamic Power
  - Related to switching activity of transistors (from  $0 \rightarrow 1$  and  $1 \rightarrow 0$ )



- Dynamic Power  $\propto C V_{dd}^2 A f$ 
  - C: capacitance, function of transistor size and wire length
  - V<sub>dd</sub>: Supply voltage
  - A: Activity factor (average fraction of transistors switching)
  - f: clock frequency
  - About 50-70% of processor power

# Power: The Basics (2/2)

- Static Power
  - Current leaking from a transistor even if doing nothing (steady, constant energy cost)



- Static Power  $\propto V_{dd}$  and  $\propto e^{-c_1 V_{th}}$  and  $\propto e^{c_2 T}$ 
  - This is a first-order model
  - $c_1, c_2$  : some positive constants
  - *V*<sub>th</sub>: Threshold Voltage
  - *T*: Temperature
  - About 30-50% of processor power

### Thermal Runaway

- Leakage is an exponential function of temperature
- ↑ Temp leads to ↑ Leakage
- Which burns more power
- Which leads to **↑** Temp, which leads to...

#### Positive feedback loop will melt your chip

# Why Power Became an Issue? (1/2)

- Ideal scaling was great (aka Dennard scaling)
  - Every new semiconductor generation:
    - Transistor dimension: x 0.7
    - Transistor area: x 0.5
    - C and  $V_{dd}$ : x 0.7
    - Frequency: 1 / 0.7 = 1.4
  - Constant dynamic power density
  - In those good old days, leakage was not a big deal

*Dynamic Power:*  $CV_{dd}^{2}Af$ 

#### 40% faster and 2x more transistors at same power

# Why Power Became an Issue? (2/2)

- Recent reality: V<sub>dd</sub> does not decrease much
  - Switching speed is roughly proportional to  $V_{dd}$   $V_{th}$ 
    - If too close to threshold voltage (V<sub>th</sub>)  $\rightarrow$  slow transistor
    - Fast transistor & low  $V_{dd} \rightarrow low V_{th} \rightarrow exponential leakage increase <math>>$

 $\rightarrow$ Dynamic power density keeps increasing

- Leakage power has also become a big deal today
  - Due to lower Vth, smaller transistors, higher temperatures, etc.
- Example: power consumption in Intel processors
  - Intel 80386 consumed ~ 2 W
  - 3.3 GHz Intel Core i7 consumes ~ 130 W
  - Heat must be dissipated from 1.5 x 1.5 cm<sup>2</sup> chip
  - This is the limit of what can be cooled by air

#### Referred to as the **Power Wall**

# How to Reduce Power? (1/3)

- Clock gating
  - Stop switching in unused components
  - Done automatically in most designs
  - Near instantaneous on/off behavior
- Power gating
  - Turn off power to unused cores/caches
  - High latency for on/off
    - Saving SW state, flushing dirty cache lines, turning off clock tree
    - Carefully done to avoid voltage spikes or memory bottlenecks
  - Issue: Area & power consumption of power gate
  - Opportunity: use thermal headroom for other cores





### How to Reduce Power? (2/3)

- Reduce Voltage (V): quadratic effect on dyn. power
  - Negative (~linear) effect on frequency
- Dynamic Voltage/Frequency Scaling (DVFS): set frequency to the lowest needed
  - Execution time = IC \* CPI \* f
- Scale back V to lowest for that frequency
  - Lower voltage  $\rightarrow$  slower transistors
  - Dyn. Power  $\approx$  C \* V<sup>2</sup> \* F

#### Not Enough! Need Much More!

# How to Reduce Power? (3/3)

- Design for E & P efficiency rather than speed
- New architectural designs:
  - Simplify the processor, shallow pipeline, less speculation
  - Efficient support for high concurrency (think GPUs)
  - Augment processing nodes with accelerators
  - New memory architectures and layouts
  - Data transfer minimization
  - ...
- New technologies:
  - Low supply voltage (V<sub>dd</sub>) operation: Near-Threshold Voltage Computing
  - Non-volatile memory (Resistive memory, STTRAM, ...)
  - 3D die stacking
  - Efficient on-chip voltage conversion
  - Photonic interconnects
  - ...

#### Processor Is Not Alone



### ISA: A contract between HW and SW

- <u>ISA</u>: Instruction Set Architecture
  - A well-defined hardware/software interface
- The "contract" between software and hardware
  - Functional definition of operations supported by hardware
  - Precise description of how to invoke all features
- No guarantees regarding
  - How operations are implemented
  - Which operations are fast and which are slow (and when)
  - Which operations take more energy (and which take less)

# Components of an ISA

- Programmer-visible states
  - Program counter, general purpose registers, memory, control registers
- Programmer-visible behaviors
  - What to do, when to do it

Example "register-transfer-level" description of an instruction

```
if imem[rip]=="add rd, rs, rt"
then
    rip ⇐ rip+1
    gpr[rd]=gpr[rs]+grp[rt]
```

• A binary encoding

### RISC vs. CISC

- Recall Iron Law:
  - (instructions/program) \* (cycles/instruction) \* (seconds/cycle)
- <u>CISC</u> (Complex Instruction Set Computing)
  - Improve "instructions/program" with "complex" instructions
  - Easy for assembly-level programmers, good code density
- <u>RISC</u> (Reduced Instruction Set Computing)
  - Improve "cycles/instruction" with many single-cycle instructions
  - Increases "instruction/program", but hopefully not as much
    - Help from smart compiler
  - Perhaps improve clock cycle time (seconds/cycle)
    - via aggressive implementation allowed by simpler instructions

#### Prototypical Processor Organization

